

Toshiba MFP Cleaning Guide

Top do's



Do

be sure to turn the power off* before cleaning in order to avoid malfunction.



Do

clean with a damp, clean disinfected towel. Do not spray disinfectant directly on MFP.



Do

pCAP-compatible stylus pen is an alternative option to touch.

*Please contact your authorised Toshiba service provider for proper steps to shut down your MFP so the hard drive is not damaged. Never simply shut down or disconnect your device.

Top don'ts



Don't

use abrasive cleaners (powders) or abrasive cleaning materials (scrub brush, scouring pad, etc.).



Don't

soak the electronic equipment with cleaning liquid.



Never

attempt to clean the following areas with alcohol: original glass, scanning area (surface of long rectangular glass).

Recommended cleaning areas:



- Control panel
- Platen cover
- Covers in the document feeder
- Side guides in the document feeder
- Jam access cover
- Side guide in the bypass tray

